



Promessa™ Series Duo Hooks Installation Procedures For The Following Models:

Cone Hooks



T101-121-BN Duo Cone Hook




T101-121-ORB Duo Cone Hook



T101-121-PC Duo Cone Hook



T101-122-BN Duo Cone Hook



T101-122-ORB Duo Cone Hook



T101-122-PC Duo Cone Hook

Tee Hooks



T101-221-BN Duo Tee Hook



T101-221-ORB Duo Tee Hook



T101-221-PC Duo Tee Hook



T101-222-BN Duo Tee Hook



T101-222-ORB Duo Tee Hook



T101-222-PC Duo Tee Hook

Thumb Hooks



T101-321-BN Duo Thumb Hook



T101-321-ORB Duo Thumb Hook



T101-321-PC Duo Thumb Hook



T101-322-BN Duo Thumb Hook




T101-322-ORB Duo Thumb Hook



T101-322-PC Duo Thumb Hook


STEP 1 Determine Hook Location



- Determine the wall surface where the PermaTile™ Fastener should be located.
- Apply thin-set mortar with no less than a 1/4" x 3/8" notch trowel.

Warning: Use only latex modified mortars that meet ANSI A118.4/A118.11 performance standard.


STEP 2 Understand Fastener



Warning: Each threaded stud is covered with a plastic thumb screw to prevent thin-set mortar from corrupting thread. Do not remove until after grouting.

- Prepackaged plastic thumb screws should not be removed until after grouting.
- Each fastener is equipped with a stabilizing bracket. The bracket ensures that hooks will mount at the predetermined location. Remove bracket after thin-set has met minimum cure times specified by manufacturer. (Using stabilizer is optional)

STEP 3 Install PermaTile™ Fastener




- Press the PermaTile™ Fastener into the combed thin-set mortar at the predetermined location.
- Key thin-set mortar into the back side of tile to ensure proper contact and adhesion.
- Adjust as necessary, setting stud directly on tile edge.

Technical Fact:

Installing the PermaTile™ Fastener on a grout joint is the simplest way. However, to insert into the body of a tile first pre-drill then back-butter tile with thin-set. Next, press fastener into thin-set and finally press to the wall (never remove plastic thumb screw during this process).

STEP 4 Notch Tile



Warning: Notches and holes should not exceed 3/8" in diameter to ensure Hook trim has sufficient surface area during mounting.





- Mark notch locations.
- Using an angle grinder, remove enough material allowing 1/16" of adjustment side to side and up and down.



TILEWARE PRODUCTS

Promessa™ Series Duo Hook Installation




STEP 5 Install Notched Tile



- Key thin-set mortar into the back side of tile to ensure proper contact and adhesion.
- Press tile into wall and adjust as necessary.
- Remount stabilizer (if removed) to maintain predetermined locations.
- This completes the fastener installation portion. Continue setting all other tile, allowing proper cure time as specified by thin-set manufacturer.

Warning: Do not proceed with accessory installation until thin-set mortar has met minimum curing requirements specified by manufacturer.

STEP 6 Mount Sleeves & Screws




Warning: Each threaded stud is covered with a plastic thumb screw to prevent thin-set mortar from corrupting thread. Do not remove until grouting is complete.

Carefully, turn 8-32 stainless steel screw. Cross-threading will require fastener removal.


- Remove plastic thumb screws & stabilizer after grouting.
- Simply slip sleeves over threaded studs, insert 8-32 stainless steel screws through sleeves and attach.
- Using a #2 phillips head screw driver, attach screws firmly to tile wall.

STEP 7 Attach Caps STEP 8 Complete



• Thread on Caps.

• Installation complete.



TileWare Products LLC
 PO Box 793
 Hickory, NC 28603
 Technical Support: 828-322-9273
 Email: info@tilewareproducts.com
www.tilewareproducts.com

Hooks Parts List

Model	Fastener Assembly quantity 1 per kit	Washer quantity 2 per kit	Sleeve quantity 2 per kit	Cap quantity 2 per kit	8-32 Screw quantity 2 per kit
T101-121 or T101-122 Cone Hook Kits	PT100-510 	C220-006 	C220-003 	C220-005 or C220-012 Transitional Traditional 	C200-013
T101-221 or T101-222 Tee Hook Kits	PT100-510 	C220-006 	C220-002 	C220-005 or C220-012 Transitional Traditional 	C200-013
T101-321 or T101-322 Thumb Hook Kits	PT100-510 	NO WASHER REQUIRED	C220-004 	C220-005 or C220-012 Transitional Traditional 	C200-013